



Auxiliary Switches

Removal

1. Release the 9 clips, disconnect the electrical connector and remove the instrument panel console cup holder.



2. Disconnect the electrical connect and remove the auxiliary switch assembly by pushing from the back.



Installation

1. To install, reverse the removal procedure.

© Copyright 2024, Ford Motor Company.