



Passenger Side Register

Removal


1. Remove the RH A-pillar trim panel.
Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Remove the passenger air bag.
Refer to: [Passenger Airbag](#) (501-20B Supplemental Restraint System, Removal and Installation).
3. Release the clips and remove the trim panels, remove the cup holder assembly.




4. Remove the retainers.




5. Remove the finish panel.
- Disconnect the electrical connector.



6. Remove the retainers and the RH trim panels.



7. Remove the passenger side register.



Installation

1. To install, reverse the removal procedure.

© Copyright 2024, Ford Motor Company.

